

model drukarki	symbol	pojemnik oryginalny	pojemnik nv
Canon BJ200/ 210/ 220/ 230 /1000 BJC 150/ 210 /220/ 240/ 250 /255 /1000	BC02	✓	✓
Canon fax B1xx/ 540/ 550/ 640/ 820/ 840 FAXPHONE B 45/ 60/ 70/ 95/ 540/ 550/ 640	BX3	✓	✓
Canon fax B340/ 360/ BJC-4xx/ 2xxx/ 4xxx/ 5xxx	BC20	✓	✓
Canon fax B210c/ 215c/ 230c/ 340/ 360/ BJC-2xxx/ 4xxx EB 10/15 FAXPHONE B740	BX20	✓	✓
Canon IP 1600/2200/MP 1710 PIXIMA 150/170/450	PG 40, PG 50	✓	✓
Canon IP 1600/2200/MP 1710 PIXIMA 150/170/450	CL 41, CL 51	✓	✓
Hewlett Packard Seria 300/ 400/ 500	51626A/G	✓	✓
Hewlett Packard DeskJet 600/ 660/ 670/ 690/ 695	51629A/G	✓	✓
Hewlett Packard DeskJet 610/ 615/ 640/ 656	C6614(20)	✓	✓
Hewlett Packard DeskJet Seria 600	51649A	✓	✓
Hewlett Packard DeskJet 710/720/820/850/870/970	51645A	✓	✓
Hewlett Packard DeskJet 840/845/920/940/810/816	C6615	✓	✓
Hewlett Packard DeskJet 816/817/825/84x FAX 1010 (ŻÓŁTA NAKLEJKA)	C6625A(17)	✓	✓
Hewlett Packard DeskJet 920/930/940/950/960/970 (ŻÓŁTA NAKLEJKA)	C6578A/D	✓	✓
Hewlett Packard DeskJet 710/720/890/895/1120/1125 (ŻÓŁTA NAKLEJKA)	C1823	✓	✓
Hewlett Packard DeskJet DeskJet 450ci/450cbi/5145/5150/5550/5551/5552/5650/5652/9650/9670/9680 OfficeJet 4105/4110/4215/4219/4255/5505/5510/5515/6110 PSC 1110/1200/1205/1210//1213/1215/1217/1219//1310/1311/1312/1315/1317/1340/1350// 1355/2100/2105/2110/2115/2150/2170/2171/2175/2179/2210/2410/2510 Photosmart 7150/7260/7350/7450/7459/7550/7660/7760/7762/7960	C6656(56)	✓	✓
Hewlett Packard DeskJet 450ci/450cbi/5145/5150/5550/5551 /5552/5650/5652/9650/9670/9680 OfficeJet 4105/4110/4215/4219/4255/5505/ 5510/5515/6110 PSC 1110/1200/1205/1210//1213/1215/1217/1219 /2110/2115/2150/2170/2171/2175/2179/2210/2410/2510 Photosmart 7150/7260/7350/7450/7459/7550/7660/7760/7762/7960	C6657(57)	✓	✓
Hewlett Packard DeskJet 450ci/450cbi/5145/5150//9670/9680 OfficeJet 4105/4110/4215/4219/4255/5505/5510/5515/6110 Photosmart 7150/7260/7350/7450/7459/7550/7660/7760/7762/7960	C6658(58)	✓	✓
Hewlett Packard DeskJet 3320/3325/3420/3425/3520/3550/3650/3740/3745/3845 PSC1310/1315	C8727A	✓	✓
Hewlett Packard DeskJet 3320/3325/3420/3425/3520/3550/3650/3740/3745/3845 PSC1310/1315	C8728A	✓	✓
Hewlett Packard 5740/6540/6840	C9362EE(336)	✓	✓
Hewlett Packard 5740/6540/6840	C8765EE(338)	✓	✓
Hewlett Packard 5740/6540/6840/8150/8450/2610	C8767EE(339)	✓	✓
Hewlett Packard 5740/6540/6840/2710/325/375	C9361EE(342)	✓	✓
Hewlett Packard 5740/6540/6840/2710/325/375	C8766EE(343)	✓	✓
Hewlett Packard 5740/6540/6840/2710/325/375	C9363EE(344)	✓	✓
Hewlett Packard 5740/6540/2610/2710/PSC 2355 FOTO	C9369EE(348)	✓	✓
Hewlett Packard 3920/3940/PCS 1410	C9351AE(21)	✓	✓
Hewlett Packard 3920/3940/PCS 1410	C9352AE(22)	✓	✓
Lexmark CJP7200/5700/3200	12A1970 /75	✓	
Lexmark CJP7200/5700/3200	12A1980 /85	✓	
Lexmark CJPZ12/Z22/Z32	17G0050	✓	
Lexmark CJPZ12/Z22/Z32	17G0060	✓	
Lexmark CJPZ13/Z23/Z25Z33/Z35	10N0016/17	✓	
Lexmark CJPZ13/Z23/Z25Z33/Z35	10N0026/27	✓	
Lexmark CJPZ42/43	15M0120	✓	
Lexmark	18L0032(L1982)	✓	
Lexmark	18L0042(L1983)	✓	

Ze względu na ciągle zmiany kursu € wg NBP nie prowadzimy stałego cennika skupu. W sprawie aktualnych cen skupu prosimy o kontakt z działem handlowym.